



Pre-Template / Measurement Process

This checklist outlines the details that you, the customer and/or the general contractor, will need to attend to before Bohemian Stoneworks can begin work measuring and making templates for your project.

- Purchase all fixtures, and have them available, along with model numbers and specifics for sink and faucets, hot/cold valves, soap dispensers, air gap dish valves, garbage disposal switches, instant hot water dispensers, stove top and back draft fans, and any other parts that affect the installation.
- Cabinetry is to be installed on a true plane and should be level to within 1/8" in ten feet. The sink should be loosely installed through a cut-out hole in the substrate at the desired location. All fixture hole locations should be marked on the substrate.
- Identify door and drawer pulls for the cabinets. The reason for this is that the drop-down edge of the counter should be able to cover the pulls when you look down from above.
- All internal corbels and brackets need to be installed for overhang countertops that exceed 8" beyond the cabinet edge.
- If a backsplash is planned, identify what kind and where the backsplash will go, and how it will be influenced by wall switches and outlets. (Extra charges can apply if countertops need to contour to irregularities in the walls -many backsplashes can hide these). Standard countertop prices reflect using backsplashes to hide a slight gap.
- Have an idea of the color, edge profile and radius corners the customer will want, in advance.
- Millwork and upper cabinets must not interfere with the concrete installation.
- Detailed drawings should be furnished as to the method and location of adjacent installations.
- Window stools to be installed above cabinet lines are to be fully gauged and all exposed surfaces finished.
- Due to the inherent weight and special requirements of concrete slabs, direct and reasonable access must be available to the area of installation.
- Inform us if there will be any decorative or raised panels on the ends of the cabinets that can affect the overhang.
- Customer should discuss seam placement with the company representative.